



(H) = HEIGHT FROM THE GROUND TO THE CENTRE OF THE SIGN FOR THE LONGEST POST.

SEE DRAWINGS 500.3-5.1 & 500.3-5.2 FOR PROVINCIAL WIND PRESSURE TABLES. (USE 1 IN 10 YEAR WIND PRESSURE)



Province of British Columbia

Ministry of Transportation and Highways

NOT TO SCALE

6" WOOD POST SIGN  
LOADING TABLE

No.	Revision	Date
F		
E		
D		
C		
B		
A	PREVIOUSLY IN CONSTRUCTION STANDARDS	SEPT96

Date Approved  
**18/11/94** **E.L. (Signature on File)**  
Chief Highway Engineer

DRAWING No.  
**500.3-2.1**