



(H) = HEIGHT FROM THE GROUND TO THE CENTRE OF THE SIGN

SEE DRAWINGS 500.3-5.1 & 500.3-5.2 FOR PROVINCIAL WIND PRESSURE TABLES. (USE 1 IN 10 YEAR WIND PRESSURE)



Province of British Columbia

Ministry of Transportation and Highways

NOT TO SCALE

No.	Revision	Date	<b>1 3/4" O.D. PERFORATED SQUARE STEEL SIGN POST LOADING TABLE</b>		DRAWING No. <b>500.3-3.2</b>
F					
E					
D					
C					
B			Date	Approved	
A	PREVIOUSLY IN CONSTRUCTION STANDARDS	SEPT96	<b>18/11/94</b>	<b>E.L. (Signature on File)</b> Chief Highway Engineer	